



10841 SO. LAUREL AVE. SANTA FE SPRINGS, CA. 90670 562-946-1907 (FAX) 562-946-5637

Part# 801391/601391
2006 Chevy HHR Bumper Billet Grille
Installation Instructions

Hardware Kit: (4) 1 ¼ Fully Threaded Studs (4) K-Lock Nuts
(4) Powder Coated Brackets (2 Long and 2 Short)

Step 1: Open the hood to gain access to the back of the bumper opening.

Step 2: Secure the fully threaded studs to the backside of the billet insert.

Step 3: Place the billet insert into the bumper pocket.

Step 4: Put the powder coated brackets over the fully threaded studs. The short powder coated brackets go on the outer fully threaded studs and the long powder coated brackets go in the center. The brackets clip on as shown in figure 1.



Figure 1

Step 5: Install the k-lock nuts onto the fully threaded studs.

Step 6: Center the billet insert into the bumper pocket and secure all hardware.

Installation Is Now Complete!!!!